



# Sierra Wireless AirCard 753S / 754S Mobile Hotspot

## User Guide



**SIERRA**  
WIRELESS™

2400159  
Rev 1



---

## Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

## Safety and Hazards

Do not operate the Sierra Wireless modem in areas where blasting is in progress, where explosive atmospheres may be present, near medical equipment, near life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the Sierra Wireless modem **MUST BE POWERED OFF**. The Sierra Wireless modem can transmit signals that could interfere with this equipment.

Do not operate the Sierra Wireless modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sierra Wireless modem **MUST BE POWERED OFF**. When operating, the Sierra Wireless modem can transmit signals that could interfere with various onboard systems.

---

*Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Sierra Wireless modems may be used at this time.*

---

The driver or operator of any vehicle should not operate the Sierra Wireless modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

## Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

## Patents

This product may contain technology developed by or for Sierra Wireless Inc. This product includes technology licensed from QUALCOMM® 3G. This product is manufactured or sold by Sierra Wireless Inc. or its affiliates under one or more patents licensed from InterDigital Group.

## Copyright

© 2011 Sierra Wireless. All rights reserved.

## Trademarks

AirCard® is a registered trademark of Sierra Wireless. Sierra Wireless™, Watcher™, and the Sierra Wireless logo are trademarks of Sierra Wireless.

Windows® and Windows Vista® are registered trademarks of Microsoft Corporation.

Macintosh® and Mac OS X® are registered trademarks of Apple Inc., registered in the U.S. and other countries.

QUALCOMM® is a registered trademark of Qualcomm Incorporated. Used under license.

Other trademarks are the property of their respective owners.

## Contact Information

Sales Desk:	Phone:	1-604-232-1488
	Hours:	8:00 AM to 5:00 PM Pacific Time
	E-mail:	sales@sierrawireless.com
Post:	Sierra Wireless 13811 Wireless Way Richmond, BC Canada V6V 3A4	
Fax:	1-604-231-1109	
Web:	www.sierrawireless.com	

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases:

[www.sierrawireless.com](http://www.sierrawireless.com)

# Contents

<b>Get Started</b>	<b>9</b>
Know Your Device	9
Power Button	10
Mute Switch	10
LCD	10
Power LED	12
Accessories	12
Power Sources	13
Set Up and Connect to the Internet	13
Insert the SIM Card	13
Connect to the Internet	15
Homepage	16
Security Credentials	18
<b>Use Your Mobile Hotspot</b>	<b>19</b>
Set Auto Connect Options	19
View Data Usage	20
Enable / Disable Wi-Fi	21
View / Block Connected Users	21
Add a Wireless Device to your Wi-Fi Network	22
View SMS Messages and Alerts	24
Use the GPS Feature	25
Battery Settings	25
Extend Battery Life	26
Set Audio Alerts	27
Change Device Security Settings	28
View Details About Your Mobile Hotspot	29
Use the microSD Card	30
Recharge the Battery	31

- Advanced Settings ..... 33**
  - Show Help for Advanced Settings ..... 33
  - Do not Automatically Install Driver for USB Tethering ..... 34
  - Export / Import Router Options ..... 35
  - Set Display Options ..... 36
  - View WAN Information. .... 36
  - Set Connection Preferences ..... 37
  - Enable SIM Security ..... 38
  - View Wi-Fi Status and List of Connected Devices. .... 39
  - Set Wi-Fi Network Options ..... 39
  - Set Wi-Fi Security Options. .... 40
  - Set MAC Filter Mode ..... 41
  - Enable Port Forwarding. .... 41
  - Enable VPN Passthrough ..... 42
  - Set Router LAN Options ..... 43
  
- Frequently Asked Questions ..... 45**
  
- Troubleshooting ..... 47**
  - Reset the Mobile Hotspot ..... 48
  - Alerts ..... 49
  
- Specifications ..... 53**
  - Mechanical Specifications ..... 53
  - Environmental Specifications. .... 53
  
- Regulatory and Safety Information ..... 55**
  - Notice. .... 55
  - Safety and Hazards ..... 55
  - Regulatory Information for North America ..... 56
  - Regulatory information for EU countries ..... 58

Regulatory information for Australia . . . . .	58
<b>Index . . . . .</b>	<b>59</b>





# >> 1: Get Started

1

This chapter provides an overview of the AirCard 753S / 754S Mobile Hotspot features, and instructions on how to set up your mobile hotspot and connect to the Internet.


## Know Your Device

Your mobile hotspot enables you to create a Wi-Fi access point anywhere there is cellular network coverage. You can use that Wi-Fi access point to connect your laptop and other Wi-Fi capable devices to your service provider's mobile broadband network and connect to the Internet.

You can also use your mobile hotspot in tethered mode by connecting it to your laptop with the USB cable to access the Internet.

Additional features include:

- GPS
- Support for microSD memory card (up to 32 GB) for storing and sharing files (Depending on your service provider, the microSD card may not be supported.)
- Wi-Fi Protected Setup (WPS)



## Power Button

Desired result	Action
Turn mobile hotspot on	Press and hold the power button for a few seconds.
Turn mobile hotspot off	Press and hold the power button for a few seconds.
Wake up LCD screen	Press and quickly release the power button.
View WPS instructions	Double-press the power button to access the Dashboard. If necessary, double-press the power button again to cycle through the Dashboard pages until the WPS instructions appear.
Respond to prompts on the LCD screen	Press and quickly release the power button when prompted to do so by the LCD screen. (This is used to confirm an action.)

## Mute Switch

The mobile hotspot automatically beeps when the battery is low, when you receive a message, etc. To turn these beeps off, move the mute switch so the red rectangle is visible. On the homepage, <http://swi.hotspot>, you can customize your hotspot to beep when specific changes in status occur. For more information, see [Set Audio Alerts](#) on page 27.

## LCD

As well as providing setup information (SSID and Wi-Fi Passphrase) the mobile hotspot LCD displays:

- Instructions during setup
- Status messages such as “Searching for network”, “Connected”, etc.
- Status icons (See [Icons on the LCD Screen](#) on page 11 for details.)
- Data Usage information
- Network name
- Error messages (See [Alerts](#) on page 49 for troubleshooting suggestions.)
- Wi-Fi Protected Setup (WPS) instructions—a fast, easy way to connect WPS-enabled devices to your Wi-Fi network

To personalize the mobile hotspot and change the settings, go to the homepage (<http://swi.hotspot>).

## Dashboard mode

More detailed information and instructions are available in the LCD Dashboard mode. To access the Dashboard, double-press the Power button. Double-press the Power button again to cycle through the Dashboard pages.

The information and instructions available on the Dashboard varies depending on your device and your service provider. Information available may include:


- Connect information (SSID and Wi-Fi Passphrase) and homepage URL

- WPS (Wi-Fi Protected Setup)—a fast, easy way to connect WPS-enabled devices to your Wi-Fi network
- Messages / Alerts
- Billing information
- Information about the mobile hotspot such as the Wi-Fi network range, network preference, firmware version, etc.

## Icons on the LCD Screen












The icons on the LCD screen indicate the status of the mobile hotspot.

### Home Screen



To enter Dashboard mode and access additional LCD screens, double-press the power button.

Icon	Indicates
	Signal strength The more bars the stronger the RF signal.
	No signal
	<p>Indicates the network type. (The icons that may appear depend on your service provider and device.)</p> <p>A Network icon with a black background indicates that service is available, but the mobile hotspot is not connected to the network.</p> <p>A network icon with a white background indicates that the mobile hotspot is connected to the network.</p>
	Roaming

Icon	Indicates
	Alerts/Messages You have alerts/messages. To view your alerts, go to the homepage and click the Alerts/Messages icon.
	GPS When the GPS icon flashes, the mobile hotspot is trying to obtain a satellite fix or is tracking a location.
	Wi-Fi users The number beside the Wi-Fi icon shows the number of users (devices) connected to your Wi-Fi network.
	Wi-Fi radio is disabled. You can enable Wi-Fi on the device homepage. See page 47— <a href="#">The Wi-Fi radio is disabled icon appears on the LCD screen.</a>
	Battery status Indicates the charge status of the battery. 4 bars — 80–100% 1 bar — 10–29%
	
	Battery outline (no bars) — 0–9% Recharge immediately.
	Battery charging
	No battery The mobile hotspot is powered on and connected to the AC charger.
	The battery is charging through a USB connection.
	The exclamation mark (!) in the battery outline indicates that the battery is not recharging because the device is too hot to charge. Make sure there is room for air to circulate around the device. If the problem persists, move the device to a cooler environment.

## Power LED

The blue LED on the top of the mobile hotspot flashes:

- Slowly to indicate that it is powered on
- Quickly when the firmware is being updated

## Accessories

Depending on your service provider, the following accessories may be included:

- Micro USB cable—Used mainly for recharging the battery, although you can also use it to tether the mobile hotspot to your computer
- AC adapter—Used with the USB cable to recharge the battery or to power the mobile hotspot from a wall socket
- Charging cradle

- Extended battery

Additional accessories are available from [www.sierrawireless.com/wheretobuy/onlinestore/default.aspx](http://www.sierrawireless.com/wheretobuy/onlinestore/default.aspx).

## Power Sources

You can power your mobile hotspot from:


- Rechargeable battery included with the mobile hotspot
- USB port on your computer
- Wall socket using the AC adapter and USB cable

## Set Up and Connect to the Internet


### Insert the SIM Card

Depending on your service provider, the SIM card may already be inserted. If you need to insert it:


1. Remove the back cover.




2. Slide the SIM card cover to the Open position.




3. Lift the SIM card cover, remove the existing SIM card and replace it with the new one.



4. Lower the SIM card cover.




5. Slide the SIM card cover to the Lock position.



---

## Install the Battery

1. Insert the battery as shown in the illustration. Ensure that the gold contacts on the battery are lined up with the gold contacts on the device.



2. Replace the back cover.

---

*Note:* Depending on your service provider, the battery may come partially-charged and ready to go. When the battery needs recharging, follow the instructions in [Recharge the Battery](#) on page 31.

---

## Connect to the Internet

---

*Note:* Your mobile hotspot does not need to be connected to the computer with the USB cable to connect to the Internet. The USB cable is used mainly for recharging the battery. (You can also connect to the Internet with the mobile hotspot tethered to the laptop with the USB cable.)

---

To connect to the Internet:

1. Turn on the mobile hotspot.  
Press and hold the power button for a few seconds. Once powered up, the mobile hotspot automatically searches for and connects to your service provider's mobile broadband network.  
The first time you connect a computer to the mobile hotspot network, the LCD screen displays the message "Connect your computer to Wi-Fi network". The SSID and the Wi-Fi Passphrase are shown on the LCD screen.

---

*Note: The LCD screen may go into sleep mode to save power. To wake up the LCD screen, press and quickly release the power button.*

---

2. Connect your computer or other device to your Wi-Fi network.
  - a. On your computer, view the list of available Wi-Fi networks.
  - b. Select the SSID displayed on the mobile hotspot LCD screen, and connect to it.
  - c. When prompted, enter your Wi-Fi Passphrase, as it appears on the mobile hotspot LCD screen.
3. Launch your browser to surf the Internet.

Optional: To personalize your mobile hotspot go to <http://swi.hotspot>.

---

*Note: To make changes to the mobile hotspot settings on the homepage, you must first log in as Administrator. Type **swiadmin** in the Admin Password field.*

---


## Homepage

Your mobile hotspot comes configured, perfectly secure and ready to use, but if you want to change the security settings, the SSID and other settings, go to your mobile hotspot's homepage.

The homepage URL (<http://swi.hotspot>) is shown on the LCD during setup. You can also find it in the Quick Start Guide that came with your mobile hotspot.

To make changes to the settings on the homepage, you must be logged in as Administrator (default Admin Password is **swiadmin**).





You can view some information about the device without being logged in as Administrator, but to view detailed information and to change any settings and use some features, you must be logged in as Administrator.

To log in as Administrator:

1. Place your cursor in the Admin Login field and type **swiadmin** (the default Admin Password).
2. Click Login.

The first time you log in, you will be asked to accept the terms and conditions. Click Agree to accept.

Once you are logged in with the default Admin Password, you can view detailed information and change mobile hotspot settings, such as:

- Change the SSID, Wi-Fi Passphrase, Admin Password, and Wi-Fi encryption
- Set autoconnect options
- Set GPS options
- Use GPS to track or map your location and find nearby amenities
- Set battery options
- View data usage
- Set audio alerts
- Change advanced settings such as security settings and router options

## Security Credentials

Two passwords are associated with the mobile hotspot:

- **Wi-Fi Passphrase**— Used to connect your computer or other Wi-Fi device to your mobile hotspot network. This character string is unique to your device. It is displayed on the main mobile hotspot LCD screen. If the screen is blank (a power-saving feature), press and quickly release the power button to view the information on the screen. The default Wi-Fi Passphrase is also printed on a label under the battery.
- **Admin Password**— Used to log into the homepage as Administrator. You must be logged in as Administrator to use certain features and to make changes to your mobile hotspot settings. The default Admin Password, **swiadmin**, is printed on a label under the battery. The Admin Password can be 5 – 31 characters.

You can change both of these passwords on the homepage, <http://swi.hotspot>. For more information, see [Change Device Security Settings](#) on page 28.

## >> 2: Use Your Mobile Hotspot

2

This chapter provides information on how to use your mobile hotspot.


*Note:* To change settings you need to be logged in as Administrator. See [Set Up and Connect to the Internet](#) on page 13.

### Set Auto Connect Options

By default, the mobile hotspot automatically connects to your service provider's mobile broadband network. You can change this feature so that the mobile hotspot automatically connects to another network when you are roaming, or to never auto connect.

To select the auto connect options:

1. On the Mobile Hotspot Homepage, log in as Administrator.
2. Click the Signal Strength icon (📶).



3. Under Auto Connect & Roaming, select the desired option:
  - Always auto connect—The mobile hotspot automatically attempts to connect to the mobile broadband network when powered on. You may incur additional roaming charges if you are outside of your service provider's coverage area.
  - Always auto connect except when roaming—The mobile hotspot automatically attempts to connect only to your service provider's mobile broadband network when powered on (default).
  - Never auto connect—The mobile hotspot will not attempt to automatically connect to the mobile broadband network when powered on.

If you choose this option, press the power button and follow the instructions on the LCD screen to connect, or go to the homepage (<http://swi.hotspot>) and click Connect. See [page 13](#) for more information.


4. Click Save. (Save button appears once you make a selection.)

## View Data Usage


You can view an estimate of your data usage (not accurate for billing purposes) on the homepage and on the LCD screen.

### On the LCD screen:


On the main screen



Network  
SSID: MyMobileHotspot  
Wi-Fi Passphrase: 12345678  
To configure your hotspot  
go to <http://swi.hotspot>

Data usage (current session)  104.2 MB 00:30:45


On the Dashboard:  
Double-press the power button until the Billing information screen appears




**Billing Info** (4/5)  
Data used from: 2011/06/18  
Data transferred: 4.23 MB\*  
Cycle restarts: 2011/07/01  
Days left: 12 days

\* approximate

### On the homepage:

1. Go to the homepage and log in as Administrator.
2. Click the Data icon (.
3. From the drop-down list, select the day of the month your billing cycle starts (typically the first of the month). This information is available on your service provider's bill.



**Data Usage Details**

**Status**

Data sent:	0.00GB	Data received:	0.00GB
Total transferred:	0.00GB	Duration:	00:00:00
WWAN IP:	0.0.0.0		

Displayed data usage is intended to help manage usage. The amounts shown are approximate, may vary

<b>Data Use</b>	<b>As of 29/08/11</b>	Restart billing cycle on day <input type="text" value="1"/> of each month
	<input type="button" value="Reset"/>	2 days left in billing cycle
<b>Total</b>	0.00 MB	


To reset the data counter manually, click Reset.

## Enable / Disable Wi-Fi

By default, Wi-Fi is enabled, but if your place of business does not allow Wi-Fi or for any reason you want to disable Wi-Fi and use the mobile hotspot only in the tethered mode, the mobile hotspot give you that option.

To enable / disable your Wi-Fi network:

1. On the Mobile Hotspot Homepage, log in as Administrator.
2. Click the Wi-Fi icon (Wi-Fi<sup>1</sup>).




3. To disable the Wi-Fi radio, beside Enable Wi-Fi, select Off.
4. Click Ok to confirm.

## View / Block Connected Users

To view a list of devices connected to your mobile hotspot and block undesired users:

1. On the Mobile Hotspot Homepage, log in as Administrator.
2. Click the Wi-Fi icon(Wi-Fi<sup>2</sup>).



If you notice a user or Wi-Fi device that you do not recognize, you can block that device from connecting to your Wi-Fi network.

To block a user (or device):

1. Select the box beside the device in the Block column.
2. Click Save. (Save button appears once you make a selection.)

To unblock a user and allow that device access to your network:

1. Click the Advanced Settings icon (⚙️).
2. Select Wi-Fi > Mac Filter.
3. Click List of connected devices.
4. Clear the box beside the device in the Block column.
5. Click Save.

## Add a Wireless Device to your Wi-Fi Network

You can connect up to five wireless devices such as smart phones, laptops, tablets, digital cameras, printers, gaming consoles, and digital picture frames to your mobile hotspot network.

You can add a wireless device to your Wi-Fi network manually, or if the device you are adding is Wi-Fi Protected Setup (WPS) enabled, you can use the WPS method.

### Manually (works for any Wi-Fi device)

1. On the wireless device you want to add to your network, view the list of available Wi-Fi networks.
2. Connect to the network that corresponds to your mobile hotspot network, as displayed on the LCD.
3. When prompted, enter the Wi-Fi Passphrase for your mobile hotspot network. The Wi-Fi Passphrase is displayed on the mobile hotspot LCD screen. (If the screen has turned off to save power, press and quickly release the power button to wake up the screen.)

### WPS (works for WPS-enabled devices)

You can add a WPS-enabled Wi-Fi device to your Wi-Fi network using the mobile hotspot LCD screen or the mobile hotspot home page.


**Using the mobile hotspot LCD screen:**

1. On your mobile hotspot, double-press the power button until you see the WPS Setup screen (2 of 5).
2. When the WPS Setup screen appears, press the power button to enable WPS.
3. Within 2 minutes, press the WPS button on the wireless device you want to connect.

Your mobile hotspot and the wireless device will communicate and establish the connection.

**Using the mobile hotspot homepage:**

1. On the Mobile Hotspot Homepage, log in as Administrator.
2. Click the Wi-Fi icon (WiFi<sup>2</sup>).
3. Click Add Device.
4. Select the Wi-Fi tab.



- If the Wi-Fi device you are adding to your Wi-Fi network does not have a PIN associated with it:
  - a. Select WPS button method.
  - b. Click Connect.
  - c. Within 2 minutes, press the WPS button on the wireless device you want to connect.

Your mobile hotspot and the wireless device will communicate and establish the connection.

- If the Wi-Fi device you are adding to your Wi-Fi network has a PIN associated with it:
  - a. Select WPS PIN method.
  - b. When prompted, enter the PIN for your Wi-Fi device.
  - c. Click the Connect button.
  - d. Within 2 minutes, press the WPS button on the wireless device you want to connect.

Your mobile hotspot and the wireless device will communicate and establish the connection.


# View SMS Messages and Alerts

Your mobile hotspot can receive SMS messages from your service provider and displays alerts to advise you of the device status.

The message icon (✉) on the device LCD indicates that you have a message or alert.

To view the message / alert:

1. On the Mobile Hotspot Homepage, log in as Administrator.
2. Click the Messages / Alerts icon (✉).



3. Click the message or alert subject line to view the entire message / alert.

To delete a message:

1. Select the desired message and then click Delete selected.

*Note: By default, you receive an audio alert when the mobile hotspot receives an SMS message / alert. For more information on Audio alerts, see [Set Audio Alerts](#) on page 27.) You cannot delete alerts. They are deleted automatically when the device status changes.*



## Use the GPS Feature

1. On the Mobile Hotspot Homepage, log in as Administrator.
2. Click the GPS icon (⊕).

The screenshot shows a web interface for GPS functionality. It is divided into two main sections: 'Status' and 'Settings'.

**Status Section:**

- Header: **Status**
- Sub-header: **GPS**
- Fields for location and movement data:
 

Latitude:	Longitude:
Altitude:	Speed:
Heading:	Satellites:
HEPE:	Timestamp:
- Buttons: 'Get GPS Location', 'Start GPS Tracking', and 'Map Me'.

**Settings Section:**

- Header: **Settings**
- Fields for configuration:
 

Mapping service:	Google Maps
Type:	Standalone
Use Metric Units:	<input type="checkbox"/>

3. Optional: Select the desired mapping service from the drop-down menu and click Save.
4. Select the desired option:
  - Get GPS Location (One-time satellite fix)
  - Start GPS Tracking (Continuous tracking)

A new window with an animated GPS satellite opens to indicate that the mobile hotspot is attempting to get a GPS fix.

If you have trouble obtaining a fix, ensure that the device has an unobstructed view of the sky and you are not near tall buildings or other barriers that could be blocking the GPS satellite signal.

5. If desired, select a mapping service.
6. Optional: Click the Map Me button on the top of the main homepage window to view your location on a map and search for nearby amenities.

## Battery Settings

The mobile hotspot, by default, is configured to optimize battery life. Battery life is affected by:

- Standby time
- Data throughput
- GPS option (GPS tracking uses more power than getting a single GPS location fix.)
- Mobile Broadband signal strength (the better the signal, the longer the battery life)


- Wi-Fi range:
  - Short Wi-Fi range—Extend battery life
  - Medium Wi-Fi range—Intermediate battery life and Wi-Fi range
  - Long Wi-Fi range—Enables you to have your laptop (or other Wi-Fi device) further from your mobile hotspot and still connect to your Wi-Fi network, but battery life is shorter.

## Extend Battery Life

There are several methods you can use to extend the battery life.

If the computer and other devices you are connecting to your Wi-Fi network are always close to the mobile hotspot device, you can increase the battery life by shortening the Wi-Fi range.

1. Go to the Mobile Hotspot Homepage and log in as Administrator. (See [Homepage](#) on page 16.)




2. In the drop-down list beside Standby Timer on Battery, select the desired time. (The shorter the time, the longer the battery life.)

The Standby Timer sets the length of time the mobile hotspot remains active when no devices are connected to the Wi-Fi network.
3. Select the desired Wi-Fi range:
  - Short Wi-Fi range—Extend battery life (default)
  - Medium Wi-Fi range—Intermediate battery life and Wi-Fi range
  - Long Wi-Fi range—Enables you to have your laptop (or other Wi-Fi device) further from your mobile hotspot and still connect to your Wi-Fi network, but battery life is shorter.
4. Click Save. (Save button appears once you make a selection.)

You can also extend the battery life by adjusting the Power LED and LCD backlight settings.

1. Go to the homepage and log in as Administrator.
2. Click the Advanced Settings icon (⚙️).
3. Select the Device tab and then select Display.



4. Set the desired options. For example, you can:
  - Turn the Power LED and LCD backlight off.
  - Set the time after which the LCD backlight turns off. (The shorter the time, the longer the battery life.)
  - Set the LCD backlight settings to DIM.
5. Click Save. (Save button appears once you make a selection.)

For more details, see [Set Display Options](#) on page 36.

## Set Audio Alerts

You can configure your mobile hotspot to sound an alert when the status changes. For example:


- When the connection status changes
- When you receive an SMS message
- When the battery is low
- When the mobile hotspot enters standby mode

To turn off all audio alerts:

1. Move the mute switch on the mobile hotspot so that the red rectangle is visible.

To choose which changes in status are accompanied by an audio alert:

1. Set the mute switch so that the red rectangle is not visible.
2. On the Mobile Hotspot Homepage, click the Alert Sounds icon (🔊).




3. Select the desired options.
4. Click Save. (Save button appears once you make a selection.)

## Change Device Security Settings

To change security settings such as Admin Password, SSID, Wi-Fi encryption, and Wi-Fi Passphrase:

1. On the Mobile Hotspot Homepage, click the Device security icon (🔒).



2. Change the desired options.
  - Admin Login: Length 5–31 characters
  - Wi-Fi passphrase: Length 5–31 characters
  - By default, the Wi-Fi Passphrase is shown on the LCD screen. If you do not want it to appear on your LCD screen, deselect the box beside Show Wi-Fi passphrase on device.

The Wi-Fi encryption options are:

- WPA2 Personal/AES — Strong security supported by newer Wi-Fi devices (default)
- WPA/WPA2 Personal — Strong security supported by most Wi-Fi devices (Use this if you want to connect Wi-Fi devices that do not support WPA2 Personal /AES.)
- None — Not recommended. Anyone can access your Wi-Fi network without a password and you are responsible for charges incurred.


The encryption options available depend on the Wi-Fi rate. To change the Wi-Fi rate and select another encryption option, go to Advanced Settings > Wi-Fi > Security. For details, see [Set Wi-Fi Security Options](#) on page 40.

3. Click Save. (Save button appears once you make a selection.)
4. You may need to reconnect your Wi-Fi devices using the new Wi-Fi credentials. See [Set Up and Connect to the Internet](#) on page 13.


## View Details About Your Mobile Hotspot

To view details about your device such as the model number, software version, IMEI, etc.:

1. Go to the Mobile Hotspot Homepage.
2. Click the About Your Mobile Hotspot icon (i).



3. For additional information and to save a file that you can forward to your service provider, click View Details. (If your service provider is troubleshooting an issue, they may ask you to save this information and email the file to them.)



4. Click Save to File.


The file is saved in your Downloads folder as a text file.

## Use the microSD Card


Your mobile hotspot is equipped with a microSD reader. You can use this feature in tethered mode to store information on the microSD card. The mobile hotspot supports microSD cards with up to 32 GB capacity.

To use the microSD card to store files:

1. Remove the back cover.



2. Insert the microSD card as shown in the illustration.



3. Replace the back cover.


4. Use the USB cable to connect the mobile hotspot to a USB port on your computer. (The first time you do this, it will take a few moments for the drivers to install.)
5. You can access the files on the microSD card through Computer / My Computer (Windows) or the Desktop (Mac).

## Recharge the Battery


The battery comes partially charged. You can recharge the battery from a wall socket or from the USB port on your computer.

To recharge the battery from a wall socket (Fastest option):

1. Attach one end of the micro USB cable to the mobile hotspot and attach the other end to the AC adapter (included).



2. Plug the AC adapter into a wall socket. An animated battery icon on the LCD screen indicates that the battery is charging.

The battery icon on the LCD screen indicates when the battery is fully charged. 


---


*Note: The LCD goes into sleep mode after a set time to extend battery life. To wake up the LCD screen, press and quickly release the power button.*

---

To recharge the battery from the USB port on your computer:

1. Attach one end of the micro USB cable to the mobile hotspot and plug the other end into the USB port on your computer. An animated battery icon indicates that the battery is charging.



The battery icon on the LCD screen indicates when the battery is fully charged. 






## 3: Advanced Settings

This chapter provides information on how to change advanced settings. The advanced settings enable you to configure various aspects of the device such as Wi-Fi settings, WAN settings, router settings, etc.

### Show Help for Advanced Settings

The Advanced Settings section of the homepage comes with built-in context-sensitive online help to assist you in configuring the mobile hotspot.


By default, online help appears when you mouse-over a field in the Advanced Settings windows.



Online Help

To hide the online help:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (🔧).
2. On the Device > Basic tab, beside Help for Advanced Settings, select Hide.



3. Click Save. (Save button appears once you make a selection.)


## Do not Automatically Install Driver for USB Tethering

By default, a host driver is installed the first time you connect your mobile hotspot to the computer via the USB cable. This driver enables the mobile hotspot to connect to the Internet when it is tethered to a USB port on the computer via the USB cable instead of using the Wi-Fi network, and to access the microSD card.

If you do not want to use this feature and want to use the USB cable only to charge the mobile hotspot battery, you can set the host driver not to install.

To set the host driver not to install:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙).
2. On the Device > Basic tab, beside Automatically install host driver for USB tethering, select No.




3. Click Save. (Save button appears once you make a selection.)

## Export / Import Router Options

You can export and import hotspot (router) settings. This is useful if you have more than one device and you want the same settings on both, or to save your settings before doing a factory reset or changing the settings.

To export router settings:

1. On the Device > Basic tab, beside Export Router Settings, click Export.




2. Save the file to the desired location.

By default, the file (export.cfg) is saved to your Downloads folder.

To import router settings:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⌨).




2. On the Device > Basic tab, beside Import Router Settings, type the path or use the Browse button to navigate to the file you want to import. (By default, router setting files are saved to your Downloads folder.)
3. Click Open, and then click OK to confirm restart.

## Set Display Options

You can use the display options to customize the mobile hotspot display and to conserve battery power.

To set the display options:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. On the Device > Display tab, select the desired options:
  - Power LED  
The Power LED blinks to confirm that the mobile hotspot is powered on. Turning it off can extend battery life.
  - LCD Backlight  
You can control how long the LCD backlight is on before going into sleep mode. You can set the LCD backlight to turn off after 10, 30 or 60 seconds, or to never turn off. (Default is 60 seconds.) To wake up the LCD, press and release the power button.
  - Backlight brightness settings  
You can control the brightness of the backlight settings when the mobile hotspot is powered by battery, USB port, or AC power. The options are off, dim, or bright.




3. Click Save. (Save button appears once you make a selection.)

## View WAN Information

To view network information, such as the active network, connection status, signal strength, etc.:


1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. Click the WAN tab.



## Set Connection Preferences

To set the connection preferences:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. Go to WAN > Setup.



3. Select the desired options.  
 You can use the manual network selection mode to select a mobile network other than your service provider's when roaming. When a network is manually selected, the device does not automatically connect to your service provider's mobile network when you re-enter your service provider's coverage area. In this case, go to the Mobile Hotspot Homepage and reset this option to use your service provider's mobile network.  
 We recommend that you leave it set to "Auto".
4. Click Save. (Save button appears once you make a selection.)


## Enable SIM Security

If desired, you can create another level of security by setting up a PIN number that must be entered before you can view the information available to an Administrator or change the mobile hotspot settings on the homepage.


If you set up a PIN number, when you go to the homepage and log in as Administrator, you will be asked to enter the PIN number before you can access the homepage as an Administrator.

To enable SIM security:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. Go to WAN > SIM.



3. Select Enable and click Save. (Save button appears once you make a selection.)




4. Enter your PIN and click Submit.  
You are allowed 5 attempts to enter the correct PIN. If you run out of available attempts the PIN will be locked. If this happens, contact your service provider to receive a PUK number to unlock the PIN.

## View Wi-Fi Status and List of Connected Devices

To view Wi-Fi status and a list of connected devices:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙).
2. Go to Wi-Fi > Status.




3. If desired, click the link to view a list of connected devices.

## Set Wi-Fi Network Options

To set the Wi-Fi network options:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙).
2. Go to Wi-Fi > Network.




3. Select the desired options.
  - SSID Broadcast — If you select Enable, your SSID (network name) will be broadcast to everyone nearby. (Select Disable if you do not want it broadcast.)
  - RTS Threshold — The smallest packet size (in bytes) used by the Request to Send/Clear to Send handshaking protocol. The recommended value is 2347. If you are experiencing inconsistent data flow, you can make minor changes to this value to try to alleviate the problem.
  - Threshold fragmentation — The largest allowable size (in bytes) for a packet. If the packet is larger than this, it is sent in multiple packets, which can affect network performance. It is recommended to keep this value as large as possible (up to 2346).
4. Click Save. (Save button appears once you make a selection.)

## Set Wi-Fi Security Options

To set the Wi-Fi security options:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. Go to Wi-Fi > Security.



3. Select the desired options and click Save.

The options available depend on the Wi-Fi rate. If you want to choose a Wi-Fi encryption other than WPA2 Personal / AES or WPA / WPA2 Personal:

1. Change the basic rate to 802.11b/g compatibility.
2. Select the desired encryption options.

Mouse-over the options for more information. (Be sure you have the Help set to Show. See [Show Help for Advanced Settings](#) on page 33.)

It is recommended that you use WPA2 Personal /AES whenever possible.

---

*Note: The length of the Wi-Fi Passphrase depends on the Wi-Fi encryption selected. Mouse-over the field for details.*

---




## Set MAC Filter Mode

MAC (Media Access Control) filtering enables you to block unauthorized Wi-Fi devices from accessing your Wi-Fi network, based on each device's MAC address.

To block a device from connecting to your Wi-Fi network:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. Go to Wi-Fi > MAC Filter.



3. Either:
  - Enter the MAC address of the device and click Add, or
  - Click List of connected devices and select the box beside the device in the Block column.
4. Click Save. (Save button appears once you make a selection.)

To unblock a device so it can connect to your Wi-Fi network:


1. Click List of connected devices.
2. Clear the box beside the device in the Block column.
3. Click Save.

## Enable Port Forwarding

If your computer is hosting a server, you can enable port forwarding so that other users can access the server.

To enable port forwarding:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. Go to Router > Basic.




3. Select Enabled beside Port Forwarding and click Save. (Save button appears once you make a selection.)

Incoming traffic is forwarded to specific ports and devices on your network (using their local IP addresses).

Note: Port forwarding creates a security risk. When not required, port forwarding should be disabled.

4. Go to Router > Port Forwarding.




5. Enter the Port Forwarding information and click Save. (Save button appears once you make a selection.)

## Enable VPN Passthrough

If you want to connect to a corporate network using VPN, you first need to enable VPN connections (passthrough).

To enable VPN passthrough:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. Go to Router > Basic.




3. Select Enabled beside VPN Passthrough, and click Save. (Save button appears once you make a selection.)

## Set Router LAN Options

To set the router LAN options:

1. On the Mobile Hotspot Homepage, click the Advanced Settings icon (⚙️).
2. Go to Router > LAN.



3. Enter the desired information.  
If the DHCP Server is enabled, it automatically assigns an IP address to each device on the network and manages their configuration information.  
The DNS Mode setting specifies how the DNS servers are obtained. If you select Auto, the servers use the DNS relay specified by the Internet provider.
4. Click Save. (Save button appears once you make a selection.)



## >> 4: Frequently Asked Questions

This chapter provides answers to questions you may have about your mobile hotspot. (Also see [Troubleshooting](#) on page 47.)

### What do I do if I forget my Wi-Fi Passphrase or Admin Password?

The Wi-Fi Passphrase appears on the LCD, unless you have configured it not to show.

The default Admin Password (**swiadmin**) is printed on a label under the battery.

If you have changed either of these and then forgotten them:

1. Reset the device to the factory settings. (See [Reset the Mobile Hotspot](#) on page 48.)
2. Use the default SSID (displayed on the LCD screen) and default Admin Password (**swiadmin**) to connect to the Wi-Fi network and log in as Administrator. See [Set Up and Connect to the Internet](#) on page 13.

### How do I disconnect from the mobile broadband network?

Do one of the following:

- On the Mobile Hotspot Homepage, click Disconnect (below the virtual mobile hotspot).
- Press and hold the power button for a few seconds to turn off the mobile hotspot.

### I can't see the Connect / Disconnect button on the homepage.

The Connect / Disconnect button is only visible when you are logged in as Administrator.

To log in as Administrator:

1. Place your cursor in the Admin Password field on the homepage and type the Admin Password (**swiadmin**).
2. Click Login.



### How can I extend the life of the battery?

For information on extending the life of the battery, see [Extend Battery Life](#) on page 26.

## How do I turn the mobile hotspot off?

Press and hold the power button for a few seconds, or click the Power off button on the homepage.

## How do I find out how many users are connected to my mobile hotspot network?

The number beside the Wi-Fi icon (  <sup>1</sup> ) on the mobile hotspot LCD shows the number of users (or devices) connected to your Wi-Fi network. For more details about the devices or users connected to your network, go to the Mobile Hotspot Homepage, log in as Administrator, and click the Wi-Fi icon (  <sup>1</sup> ).

---

*Note: You can also use the options on the homepage to block particular users from connecting to your network. See [View / Block Connected Users](#) on page 21.*

---

## The LCD screen is not lit. How do I know if the mobile hotspot is still powered on?


The LCD screen dims to save energy. The blue LED continues to flash (provided you have not turned this feature off) to indicate that the mobile hotspot is still powered on. To wake up the LCD, press and quickly release the power button.

## How do I access information on the microSD card?

1. Insert the microSD card. (See [Use the microSD Card](#) on page 30.)
2. Use the USB cable to connect the mobile hotspot to a USB port on your computer.

You can access the files on the microSD card through Computer / My Computer (Windows) or the Desktop (Mac).

## Where can I find more information?



- View the Online Help:
  1. Go to the Mobile Hotspot Homepage. (See [Homepage](#) on page 16.)
  2. Click the Help icon (  ).
- Go to [www.sierrawireless.com/support](http://www.sierrawireless.com/support) and select your service provider and product (For example, AirCard 754S or AirCard 753S). From the Sierra Wireless Web site, you can:
  - Update the firmware on your device
  - View product documentation
- Refer to the Quick Start Guide that came with your mobile hotspot.

## 5: Troubleshooting


This chapter provides suggestions for troubleshooting problems that may arise when using your mobile hotspot.

### The mobile hotspot network name does not appear in the list of networks.


Refresh the list of networks.

1. Ensure that the Wi-Fi setting on your laptop (or other device) is turned on.
2. Ensure that Wi-Fi is enabled on the mobile hotspot. The Wi-Fi icon on the LCD should have a "O" beside it  (not an "X" .

If you need to enable Wi-Fi on the mobile hotspot:


1. Use the USB cable to tether the mobile hotspot to your laptop. (The first time you do this, it will take a few moments for the drivers to install.)
2. Launch your browser and go to the Mobile Hotspot Homepage (<http://swi.hotspot>).
3. Click the Wi-Fi users icon (.
4. Under Enable Wi-Fi, select On.
5. Click Save.

### The No Signal icon appears on the LCD screen.

If the No Signal icon () appears on the LCD screen, make sure you are in your service provider's coverage area.

### The Wi-Fi radio is disabled icon appears on the LCD screen.

If the Wi-Fi radio is disabled icon () appears on the LCD screen:

1. Use the USB cable to tether the mobile hotspot to your laptop.
2. Launch your browser and go to the Mobile Hotspot Homepage.
3. Click the Wi-Fi users icon (.
4. Under Enable Wi-Fi, select On.
5. Click Save.

## Unable to access the homepage when connected to a VPN.

If you are using your mobile hotspot while connected to a VPN, you may not be able to access the mobile hotspot using <http://swi.hotspot>.

To access the homepage, enter the address <http://192.168.1.1> in your browser. This directly accesses the homepage hosted on the device.

## Unable to connect a computer running Windows® Vista® to the Mobile Hotspot


Microsoft has a known issue whereby computers running Windows Vista cannot obtain an IP address from certain routers. More information and a fix are available at <http://support.microsoft.com/kb/928233> or go to the Microsoft support Web site and search for knowledge base article 928233.

## Reset the Mobile Hotspot


You can reset the Mobile hotspot to the factory setting on the device or on the Mobile Hotspot Homepage. This is useful if you have lost your Wi-Fi Passphrase.

### To reset the mobile hotspot on the device:

1. Ensure that the mobile hotspot is powered on.
2. Remove the back cover.



3. Use a small object such as the end of a paper clip to press and hold the reset button for 5 to 10 seconds.






4. When prompted on the LCD to do so, press the power button to confirm the reset.
5. Replace the back cover.
6. Reconnect Wi-Fi devices.

## To reset the mobile hotspot on the Mobile Hotspot Homepage:

1. On the Mobile Hotspot Homepage, click the About Your Mobile Hotspot icon (i).
2. Click Reset Device to Factory Defaults.



3. Click OK to confirm.
4. Reconnect Wi-Fi devices.

## Alerts

### SIM not installed

Ensure that the SIM card is installed correctly. See [Insert the SIM Card](#) on page 13.

### SIM Error — Check SIM

Ensure that the SIM card inserted in your mobile hotspot is from your service provider. If there is still a problem, contact your service provider. (The SIM may be damaged and need replacing.)

### SIM Locked

1. Contact your service provider for the PIN to unlock the SIM.
2. Go to the Mobile Hotspot Homepage. (See [Homepage](#) on page 16.)
3. Log in as Administrator. (See [Security Credentials](#) on page 18.)
4. Enter the SIM PIN when prompted.
5. Click Save.

### SIM MEP Locked

1. Contact your service provider for the MEP unlock codes and tool to unlock your Mobile Hotspot.

### Temperature-related alerts

The mobile hotspot is designed to work over a wide temperature range. (See [Environmental Specifications](#) on page 53 for details.) If you are outside that temperature range, the mobile hotspot issues an alert.

Move the device to an area where the temperature is more suitable and, if the mobile hotspot is too warm, make sure the area is well-ventilated and air can circulate around the device.

---

*Note: The battery may not recharge if the mobile hotspot is outside the operating temperature range.*

---

### WPS Setup Failed; Device not connected!

The device you are trying to connect may not be WPS-enabled. Use the manual method to connect the W-Fi device to your Wi-Fi network.

1. Open the Wi-Fi menu on the device you are trying to connect to the Wi-Fi network.
2. Select your Network Name from the list of available Wi-Fi networks.
3. Select Connect and when prompted, enter your Wi-Fi Passphrase.

### Connection Alerts

If you receive any of the following connection alerts, contact your service provider and provide them with the name and number of the alert.

**Table 5-1: Connection alerts**

Alert	Description
8	Operator Determined Barring
25	LLC or SMDCP failure
26	Insufficient resources

**Table 5-1: Connection alerts**

Alert	Description
27	Missing or unknown APN
28	Unknown PDP address or type
29	User authentication failed
30	Activation rejected by GGSN
32	Service Option not supported
33	Service Option not subscribed
34	Service Option temporarily out of order
36	Regular deactivation
37	QOS not accepted
38	Network failure
39	Reactivation required
40	Feature not supported
41	Semantic error in the TFT operation
42	Syntactical error in the TFT operation
43	Unknown PDP context
44	PDP context without TFT already activated
45	Semantic errors in packet filter(s)
46	Syntactical errors in packet filter(s)
67	Connection error
81	Invalid transaction identifier value
95	Semantically incorrect message
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message type not compatible with the protocol state
99	Information element non-existent or not implemented
100	Conditional IE error
101	Message not compatible with the protocol state
111	Protocol error, unspecified
256	Invalid Connection ID
257	Invalid NSAPI
258	Invalid PRI NSAPI

**Table 5-1: Connection alerts**

Alert	Description
259	Invalid Field
260	SND CP Failure
261	RAB Setup Failure
262	No GPRS Context
263	PDP Establish Max Timeout
264	PDP Activate Max Timeout
265	PDP Modify Max Timeout
266	PDP Inactivate Max Timeout
267	PDP Lower layer Error
268	PDP Duplicate
269	UE RAT Change

## >> 6: Specifications

### Mechanical Specifications

Weight	100g (3.53 oz.)
Length	96 mm (3.78 in.)
Width	57 mm (2.24 in.)
Thickness	16.5 mm (0.65 in.)

### Environmental Specifications

Operating temperature	0° C to 35° C (32° F to 95° F)
Storage temperature	-10° C to +65° C, 96 hours (14° F to 149° F)



## 7: Regulatory and Safety Information

## 7

### Notice

Because of the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (that is, have errors), or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the AirCard 753S / AirCard 754S Mobile Hotspot are used in a normal manner with a well-constructed network, the AirCard 753S / AirCard 754S Mobile Hotspot should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless and its affiliates accept no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the AirCard 753S / AirCard 754S Mobile Hotspot, or for failure of the AirCard 753S / AirCard 754S Mobile Hotspot to transmit or receive such data.

### Safety and Hazards

The mobile hotspot **MUST BE POWERED OFF** in all areas that may be susceptible to radio interference, in particular:

- Prohibited areas  
Obey all signs and notices and follow all rules and regulations. Power off the mobile hotspot when instructed to do so or when you suspect that it may cause interference or danger.
- In areas where blasting is in progress
- Where explosive atmospheres may be present  
Areas with a potentially explosive atmosphere are not always clearly marked. Such areas include gas stations, fuel depots, chemical transfer or storage facilities, areas where blasting is in progress, areas where the air contains chemicals or particles such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your cellular phone or vehicle engine.
- Near medical or life-support equipment  
Medical equipment may be susceptible to any form of radio interference. In such areas the mobile hotspot can transmit signals that could interfere with this equipment.
- On board aircraft  
In addition to Federal Aviation Authority (FAA) requirements, many airline regulations state that you must suspend wireless operations before boarding an aircraft. The mobile hotspot is

capable of transmitting signals that could interfere with various onboard systems and controls.

Failure to observe this instruction may lead to suspension or denial of cellular telephone services to the offender, legal action, or both.

Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. The mobile hotspot may be used normally at this time.

- While operating a vehicle

The driver or operator of any vehicle should not use a wireless data device while in control of a vehicle. Doing so detracts from the driver or operator's ability to control and operate the vehicle. In some countries, using such communications devices while in control of a vehicle is an offence.

---

**Caution:** *Unauthorized modifications or changes not expressly approved by Sierra Wireless, Inc. could void compliance with regulatory rules, and thereby your authority to use this device.*

---

## Proper Battery Use and Disposal

---

*Note: Improper battery use may result in a fire, explosion, or other hazard.*

---

To ensure safe and responsible battery use:

- Do not open, disassemble, puncture, crush, bend, or shred.
- Do not expose to water or other liquids, fire, explosion, or other hazards.
- Use the battery only in the mobile hotspot.
- If using with a charger, use only the charger supplied with the mobile hotspot.
- Do not short circuit the battery.
- When replacing a battery, use the same model of battery that was supplied with the mobile hotspot.
- Follow local regulations when disposing of a used battery.
- Avoid dropping the mobile hotspot or the battery. If dropped and you suspect damage, take it to a service center for inspection.

## Regulatory Information for North America

---

---

*Note: Regulatory information in this section applies to the AirCard 754S Mobile Hotspot.*

---

**Caution:** *The AirCard 754S Mobile Hotspot must be 1 cm or more from users during operation, to satisfy FCC / IC RF exposure requirements.*

---

This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that these devices do not cause harmful interference.



Where appropriate, the use of the equipment is subject to the following conditions:

---

*Note: **(EMI)** – United States FCC Information – This equipment has been tested and found to comply with the limits pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in an appropriate installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation.*

---

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

If you have purchased this product under a United States Government contract, it shall be subject to restrictions as set forth in subparagraph (c)(1)(ii) of Defense Federal Acquisitions Regulations (DFARs) Section 252.227-7013 for Department of Defense contracts, and as set forth in Federal Acquisitions Regulations (FARs) Section 52.227-19 for civilian agency contracts or any successor regulations. If further government regulations apply, it is your responsibility to ensure compliance with such regulations.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## Regulatory information for EU countries

---

*Note: Regulatory information in this section applies to the AirCard 753S Mobile Hotspot.*

---

To ensure safe use, the modem must be 1 cm or more from users during operation.

Sierra Wireless hereby declares that the Sierra Wireless USB wireless modem conforms to all the essential requirements of Directive 1999/5/EC:



The Declaration of Conformity made under Directive 1999/5/EC is available for viewing at the following location in the EU community:

Sierra Wireless (UK) Limited  
Suite 5, the Hub  
Fowler Avenue  
Farnborough Business Park  
Farnborough, United Kingdom GU14 7JP

**Notice:** User restrictions for Wi-Fi operation apply in France. Please check with French authorities before using this device in France.

## Regulatory information for Australia

---

*Note: Regulatory information in this section applies to the AirCard 753S Mobile Hotspot.*

---

To ensure safe use, the modem must be 1 cm or more from users during operation.

# >> Index

## A

accessories  
    included, [12](#)  
    purchasing optional accessories, [13](#)  
add a wireless device, [22](#)  
Admin Login, forgot, [45](#)  
Admin Password, [18](#)  
Admin Password, forgot, [45](#)  
audio alerts, [27](#)  
auto connect options, [19](#)

## B

battery, [25](#)  
    inserting, [15](#)  
    recharging, [31](#)  
battery life, [45](#)  
block users, [21](#)

## C

connect / disconnect button, [45](#)  
connect to the Internet, [13](#)  
connect to the Internet,, [15](#)  
connection preferences, [37](#)

## D

display options, [36](#)

## G

GPS, [25](#)

## H

homepage, accessing, [16](#)  
homepage, cannot access, [48](#)

## I

icons on the LCD screen, [11](#)

## L

LAN options, [43](#)  
LCD, [10](#)  
LCD screen not lit, [46](#)  
list of connected devices, view, [39](#)

## M

MAC filter, [41](#)  
microSD  
    accessing information on, [46](#)  
    inserting, [30](#)  
microSD card  
    accessing information on, [30](#)  
mobile hotspot, turn off, [46](#)  
mute switch, [10](#)

## N

network name does not appear in the list of networks, [47](#)  
no signal icon, [47](#)

## P

port forwarding, [41](#)  
power button, [10](#)  
power source, [13](#)

## R

regulatory information, [55](#)  
router options, import, export, [35](#)

## S

safety information, [55](#)  
Security credentials  
    forgot, [45](#)  
security credentials, [18](#)  
security, change settings, [28](#)  
show Help for advanced settings, [33](#)  
SIM card, inserting, [13](#)  
SIM security, enable, [38](#)  
SMS messages, [24](#)  
specifications, [53](#)

## T

text messages. *See* SMS messages.  
troubleshooting, [47](#)

## U

USB tethering, [34](#)

## V

view connected users, [21](#)  
VPN passthrough, [41](#), [42](#)

### W

WAN information, view, [36](#)

Wi-Fi Key, forgot, [45](#)

Wi-Fi network

    disconnect, [45](#)

    options, [39](#)

Wi-Fi Passphrase, [18](#)

Wi-Fi Passphrase, forgot, [45](#)

Wi-Fi radio is disabled, [47](#)

Wi-Fi range, [26](#)

Wi-Fi security options, [40](#)

Wi-Fi status, view, [39](#)

Wi-Fi, enable/disable, [21](#)



